



Ultrasound Solutions

Product Catalogue

Main kits, accessories and spare parts



May 2014

Content

Sets

Receivers

○ SDT200 & SDT270	4
○ SDT 170 MTT	5
○ Sherlog	5
○ FLEX.US	6

○ Transmitters	6
----------------	---

Accessories, spare parts and others

Ultrasonic sensors

○ Flexible sensors	7
○ Contact probes	8
○ Threaded sensors	9
○ Other ultrasonic sensors	9

○ Non ultrasonic sensors	10
--------------------------	----

○ Sensor accessories	10
----------------------	----

○ Cables	12
----------	----

○ Listening and recording accessories	15
---------------------------------------	----

○ Batteries	16
-------------	----

○ Battery chargers	17
--------------------	----

○ Cases	19
---------	----

Tank test Accessories

○ Tank test sensors	20
○ Tank test pipes	20
○ Other tank test accessories	21

○ Spare receivers	25
-------------------	----

○ Spare transmitters	26
----------------------	----

○ Demonstration equipment	26
---------------------------	----

○ Spare parts SDT 170/Sherlog	27
-------------------------------	----

○ Leak tags	29
-------------	----

○ SDT270 upgrade keys	29
○ Software	30
○ Calibration and functional tests	30

Appendices

○ Remarks concerning battery loaders and power cables	32
○ Sensors & accessories: compatibility and required cables	33
○ Contact sensors overview	34
○ Requirements concerning accelerometers	35

Part number	Description
SDT200 & SDT270 sets	
FSR200ASD	KIT SDT200 SD ATEX (BASIC)
	
FAHOLSAC-01	SHOULDER STRAP SDT170, SDT8 & SWITCHBOX
FAHOLSAC-02	LEATHER STRIP - BELT HOLDER W/ CLIP
FUBATTR270A	BATTERY PACK SDT270 / SDT200 ATEX- 4,8V 4000mAh NiMh - with Cable As
FUCABLPWRC7EU-01	POWER CORD 1,5m C7F - EURO
FUHDPH-7	HEADPHONE SET SDT BLUE NECK - ATEX
FUPWSPUN-01	BATTERY CHARGER UNIVERSAL (SDT170 - 270) W/O CORD (FUCABLPWRC7xx)
FUR200ASD	SDT200 RECEIVER ATEX W/ MANUAL, RUBBER CURB RING & W/O BATTERY
FUSUITSYS3T-1	SYSTAINER 3 T-LOC PLASTIC CASE W/ FOAM R200/R270, FOLIO
SICABUSBAUSBBM	CABLE USB TYPE A - B5 MINI
FSR200SD	KIT SDT200 SD (BASIC)
	
FAHOLSAC-01	SHOULDER STRAP SDT170, SDT8 & SWITCHBOX
FAHOLSAC-02	LEATHER STRIP - BELT HOLDER W/ CLIP
FUBATTR270	BATTERY PACK SDT270 / SDT200 - 4,8V 4000mAh NiMh
FUCABLPWRC7EU-01	POWER CORD 1,5m C7F - EURO
FUHDPH-1	HEADPHONE SET SDT BLUE NECK
FUPWSPUN-01	BATTERY CHARGER UNIVERSAL (SDT170 - 270) W/O CORD (FUCABLPWRC7xx)
FUR200SD	SDT200 RECEIVER W/ MANUAL, RUBBER CURB RING & W/O BATTERY
FUSUITSYS3T-1	SYSTAINER 3 T-LOC PLASTIC CASE W/ FOAM R200/R270, FOLIO
SICABUSBAUSBBM	CABLE USB TYPE A - B5 MINI
FSR270ASB	KIT SDT270 ATEX SB (BASIC)
	
FAHOLSAC-01	SHOULDER STRAP SDT170, SDT8 & SWITCHBOX
FAHOLSAC-02	LEATHER STRIP - BELT HOLDER W/ CLIP
FARPMNLABEL	REFLECTIVE LABEL FOR RPM (PACK OF4 PCS)
FUBATTR270A	BATTERY PACK SDT270 / SDT200 ATEX- 4,8V 4000mAh NiMh - with Cable As
FUCABLPWRSETC7	POWER CORD C7 SET (EU-US)
FUHDPH-7	HEADPHONE SET SDT BLUE NECK - ATEX
FUPWSPUN-01	BATTERY CHARGER UNIVERSAL (SDT170 - 270) W/O CORD (FUCABLPWRC7xx)
FUR270ASB	SDT270 RECEIVER ATEX W/ BLUE ATEX RUBBER PROTECTION & W/O BATTERY
FUSUITSYS3T-1	SYSTAINER 3 T-LOC PLASTIC CASE W/ FOAM R200/R270, FOLIO
SICABUSBAUSBBM	CABLE USB TYPE A - B5 MINI
FSR270SB	KIT SDT270 SB (BASIC)
	
FAHOLSAC-01	SHOULDER STRAP SDT170, SDT8 & SWITCHBOX
FAHOLSAC-02	LEATHER STRIP - BELT HOLDER W/ CLIP
FARPMNLABEL	REFLECTIVE LABEL FOR RPM (PACK OF4 PCS)
FUBATTR270	BATTERY PACK SDT270 / SDT200 - 4,8V 4000mAh NiMh
FUCABLPWRC7EU-01	POWER CORD 1,5m C7F - EURO
FUHDPH-1	HEADPHONE SET SDT BLUE NECK
FUPWSPUN-01	BATTERY CHARGER UNIVERSAL (SDT170 - 270) W/O CORD (FUCABLPWRC7xx)

Product list - main kits, accessories and spare parts

Part number	Description
FUR270SB	SDT270 RECEIVER W/ BLUE RUBBER PROTECTION & W/O BATTERY
FUSUITSYS3T-1	SYSTAINER 3 T-LOC PLASTIC CASE W/ FOAM R200/R270, FOLIO
SICABUSBAUSBBM	CABLE USB TYPE A - B5 MINI

SDT270 TankTest sets

SDT270TankTest



KIT SDT270 TankTest Basic EX EU W/O PUMP

Consists of:

DQCERT	CERTIFICATE
FAUPGRKEY270TT	SDT270 TT UPGRADE KEY - TANKTEST KEY & TANKTEST REPORTER LICENSE
FSR270ASB	KIT SDT270 ATEX SB (BASIC)
FU.TTSY.TTS2.003	CAMLOCK 2" W/ 2x SENSOR TTS2 Ex TANK TEST - LEMO7PM (RED/ BLACK), L= 50dm - VITON
FUCABLSPLE7BNC18	CABLE SPIRAL- LEMO 7P<> BNC, L= 6/18dm
FUFLEXEX1	FLEXIBLE 550mm BNC ATEX W/ REMOVABLE SENSOR 16mm & EXTENSION
FUSUITSYS1-2	SYSTAINER 1 PLASTIC CASE SDT W/ BOTTOM FOAM & NABA
FUTTPICONTUB2	TANK CONNECTION TUBE 2" - 50cm KA2" M - G2" F W/ NIPPLE 2" & O-RING 48 x 6
FUTTPIRUBI5	RUBBER PIPE 1" TANK TO PUMP Ex-PROOF L=5m W/O FLAME BUSTER (2x CAMLOCK 1" FEMALE - INPUT)
FUTTPIRUBO5	RUBBER PIPE 1" PUMP EXHAUST Ex-PROOF L=5m W/ FLAME BUSTER (2x CAMLOCK 1" FEMALE- OUTPUT)

Sherlog sets

SherlogCadet



SHERLOG Kit - Cadet

Consists of:

FAHOLSSET8MS	LEATHER CASE FOR SDT8 W/ SHOULDER STRAP
FUFLUS-01	FLEX.US RECEIVER
FUHDPH-1	HEADPHONE SET SDT BLUE NECK
FUPWSP8/EU*	BATTERY CHARGER SDT8 - 100-240 EU
FUSUITSYS3T-1	SYSTAINER 3 T-LOC PLASTIC CASE W/ FOAM R200/R270, FOLIO
FUT008MSMG	SDT8 TRANSMITTER, SHERLOG RED W/ BATTERY
FUTOOLSCRDRIV	SCREW DRIVER FOR BATTERY COVER SDT150, SDT8 & SDT13
SIBAT1,5VALK-AA	BATTERY ALKALINE 1,5V AA
SICMPUSBMEM-01	USB FLASH DRIVE TWIST 2GB 57x19x10mm - BLEU FONCE + IMPRESSION 2 FACES - BOITE BLANCHE TRANSLUCIDE
SIRUBSENS18MMSI	RUBBER FOR SENSOR Ø18mm

SherlogMaster



SHERLOG Kit - Master

Consists of:

FAHOLSSET8MS	LEATHER CASE FOR SDT8 W/ SHOULDER STRAP
FAUPGRKEY270SH	SDT270 SH UPGRADE KEY - SHERLOG + DOWNLOAD WITH SHERLOG REPORTER
FSR270SB	KIT SDT270 SB (BASIC)
FUBATTAD8	BATTERY CHARGER ADAPTER SDT8
FUBATT008	BATTERY SDT8 12V/1.2Ah
FUFLEX825SH	FLEXIBLE 820mm SH - FlexID1 - REMOV.10mm SHERLOG (w/ TUBE 400mm)
FUPWSP8/EU*	BATTERY CHARGER SDT8 - 100-240 EU
FUT008MS	SDT8 TRANSMITTER, BLUE W/ BATTERY
FUTOOLSCRDRIV	SCREW DRIVER FOR BATTERY COVER SDT150, SDT8 & SDT13

SherlogMate



SHERLOG Kit - Mate

Consists of:

FAHOLSSET8MS	LEATHER CASE FOR SDT8 W/ SHOULDER STRAP
--------------	---



Ultrasound
Solutions

* Please check the appendix of this catalogue for remarks concerning the battery loader and power cable types.

Price list 20140508

Printed on 19/05/2014

Product list - main kits, accessories and spare parts

Part number	Description
FSR200SD	KIT SDT200 SD (BASIC)
FUBATTAD8	BATTERY CHARGER ADAPTER SDT8
FUBATT008	BATTERY SDT8 12V/1.2Ah
FUFLEX825SH	FLEXIBLE 820mm SH - FlexID1 - REMOV.10mm SHERLOG (w/ TUBE 400mm)
FUPWSP8/EU*	BATTERY CHARGER SDT8 - 100-240 EU
FUT008MS	SDT8 TRANSMITTER, BLUE W/ BATTERY
FUTOOLSCRDRIV	SCREW DRIVER FOR BATTERY COVER SDT150, SDT8 & SDT13

Flex.Us sets

FSFLUS	KIT FLEX.US
	
DMFLUS-01	USER'S MANUAL FLEX.US SDT
FUFLUS-01	FLEX.US RECEIVER
FUHDPH-2	HEADPHONE SET SDT BLUE FOLD
FUSUITFLUS	PLASTIC CASE FLEX.US (BLUE) W/ FOAM
SIBAT1,5VALK-AA	BATTERY ALKALINE 1,5V AA
SIPABOVAL002-02	BOX AMERICAINE - 330x300x108mm INT. - FEFCO 204 KRAFT 170gr SIMPLE CANNELURE B
SIRUBSENS18MMSI	RUBBER FOR SENSOR Ø18mm

FSFLUS-03	KIT FLEX.US w/ SYSTAINER 3 T-LOC (BASIC)
	
DMFLUS-01	USER'S MANUAL FLEX.US SDT
FUFLUS-01	FLEX.US RECEIVER
FUHDPH-1	HEADPHONE SET SDT BLUE NECK
FUSUITSYS3T-1	SYSTAINER 3 T-LOC PLASTIC CASE W/ FOAM R200/R270, FOLIO
SIBAT1,5VALK-AA	BATTERY ALKALINE 1,5V AA
SIRUBSENS18MMSI	RUBBER FOR SENSOR Ø18mm

FSFLUSE/EU*	KIT FLEX.US W/ TRANSM. EU
	
DMFLUS-01	USER'S MANUAL FLEX.US SDT
FUFLUS-01	FLEX.US RECEIVER
FUHDPH-2	HEADPHONE SET SDT BLUE FOLD
FUPWSP150/EU-02*	BATTERY CHARGER SDT150 & 200 mW 100-240 EU FRIWO PLUG
FUSUITFLUS	PLASTIC CASE FLEX.US (BLUE) W/ FOAM
FUT200B	200 mW BI-SONIC TRANSMITTER
SIBAT1,5VALK-AA	BATTERY ALKALINE 1,5V AA
SIPABOVAL002-02	BOX AMERICAINE - 330x300x108mm INT. - FEFCO 204 KRAFT 170gr SIMPLE CANNELURE B
SIRUBSENS18MMSI	RUBBER FOR SENSOR Ø18mm

Transmitter sets

FST008MS/EU*	KIT SDT8 MULTISETTING EU
	
DMR170CD	USER'S MANUAL SDT170 (CD)
FAHOLSSET8MS	LEATHER CASE FOR SDT8 W/ SHOULDER STRAP
FUBATTAD8	BATTERY CHARGER ADAPTER SDT8
FUBATT008	BATTERY SDT8 12V/1.2Ah

* Please check the appendix of this catalogue for remarks concerning the battery loader and power cable types.

Product list - main kits, accessories and spare parts

Part number	Description
FUPWSP8/EU*	BATTERY CHARGER SDT8 - 100-240 EU
FUSUIT8	PLASTIC CASE (BLUE) SDT8 W/ FOAM
FUT008MS	SDT8 TRANSMITTER, BLUE W/ BATTERY
FUTOOLSCDRIV	SCREW DRIVER FOR BATTERY COVER SDT150, SDT8 & SDT13
FUSEUSTC18/J3M	SENSOR 18mm TRANSM. CLOSED - JACK 3,5 - CABLE 2,5m - FOR SDT200mW
	Consists of: LABOUR COST - (min) (1) R280560000 SMB CABLE SLEEVE 2,6mm BLACK - RG174 - RADIALL RG174A/U CABLE COAXIAL 50R - Ø2,8mm -BLACK (2170001) KLS22 PLUG 3,5mm MONO CABLE PART W/ SLEEVE, STEEL HOUSING (LUMBERG) PATTEX TIX-GEL TUBE CONTACTLIJM - 147ml/125g - HENKEL RUBBER FOR SENSOR Ø18mm 400ET180 CLOSED ULTRASONIC SENSOR TRANSMITTER Ø 18mm (SQ-40T18CL)
ABPRODTIME	
SIBUSHSMBR280560	
SICABRG174BLA	
SICONCAADP3M-01	
SIGLUEPATIX-125	
SIRUBSENS18MMSI	
SISENSUS40T18CL-01	
FUT200SETBPS/EU*	200mW BI-SONIC TRANSMITTER W/ LOADER SDT150 & 200mW EU
	Consists of: BATTERY CHARGER SDT150 & 200 mW 100-240 EU FRIWO PLUG 200 mW BI-SONIC TRANSMITTER
FUPWSP150/EU-02*	
FUT200B	

Flexible sensors

Flexible sensors

FUFLEX306	FLEXIBLE 300mm BNC W/ REMOVABLE SENSOR 16mm
	
FUFLEX555	FLEXIBLE 550mm BNC W/ REMOVABLE SENSOR 10mm
	
FUFLEX556	FLEXIBLE 550mm BNC W/ REMOVABLE SENSOR 16mm
	
FUFLEX825	FLEXIBLE 820mm BNC W/ REMOVABLE SENSOR 10mm
	
FUFLEX825SH	FLEXIBLE 820mm SH - FlexID1 - REMOV.10mm SHERLOG (w/ TUBE 400mm)
	

Product list - main kits, accessories and spare parts

Part number	Description
FUFLEX826	FLEXIBLE 820mm BNC W/ REMOVABLE SENSOR 16mm
	
FUFLEX826SH	FLEXIBLE 820mm SH - FlexID1 - REMOV.16mm SHERLOG (w/ TUBE 400mm)
	
FUFLEXEX1	FLEXIBLE 550mm BNC ATEX W/ REMOVABLE SENSOR 16mm & EXTENSION
	
FUFLEXEX2	FLEXIBLE 550mm BNC ATEX W/ REMOVABLE SENSOR 10mm & EXTENSION
	


Contact probes

FUSOND270-01--A	RS1NL100 NEEDLE CONTACT PROBE (L=82mm) W/O CABLE
	
FUSOND270-02--A	RS1NL300 NEEDLE CONTACT PROBE (L=275mm) W/O CABLE
	
FUSOND270-03--A	RS1NL500 NEEDLE CONTACT PROBE (L=470mm) W/O CABLE
	
FUSOND270A-01--A	RS1NL100 NEEDLE CONTACT PROBE ATEX (L=82mm) W/O CABLE
	
FUSOND270A-02--A	RS1NL300 NEEDLE CONTACT PROBE ATEX (L=275mm) W/O CABLE
	
FUSOND270A-03--A	RS1NL500 NEEDLE CONTACT PROBE ATEX (L=470mm) W/O CABLE
	

Threaded sensors

Product list - main kits, accessories and spare parts

Threaded sensors

Part number	Description
FUSCRS3-01--A	THREADED SENSOR RS1T
	
FUSCRS3A-01--A	THREADED SENSOR RS1T ATEX
	

Other ultrasonic sensors

Other ultrasonic sensors

FS.PAR2.001	ParaDish2 - PARABOLIC SENSOR w/systainer 1
	
FS.PAR2.002	ParaDish2 - PARABOLIC SENSOR ATEX w/systainer 1
	
FUSEUSCOLL01	SENSOR BUILT IN REFLECTOR- BNCW/O CABLE
	
FUSEUSRC08/LE7	SENSOR 8mm R CLOSED - LEMO 7 CABLE 2,5m
	
FUSEUSRC18/LE7	SENSOR 18mm R CLOSED - LEMO 7 CABLE 2,5m
	
FUSEUSRO10/LE7	SENSOR 10mm R OPEN - LEMO 7 CABLE 2,5m
	
FUSEUSRO16/LE7	SENSOR 16mm R OPEN - LEMO 7 CABLE 2,5m
	

Non ultrasonic sensors

FU.HUMS.001	HUMIDITY SENSOR
	

Product list - main kits, accessories and spare parts

Part number

Description

FUMFLP1K

SENSOR MFL LOW PRESSURE 1000 SCCM



SISENSAMHS130

HS130 ACCELEROMETER, TOP ENTRY 100mV/g, M6x1 FEMALE, M8-CONNECTOR



Sensor accessories

FAFLEXSENS10R

REMOVABLE SENSOR 10mm FOR FLEX



FAFLEXSENS16R

REMOVABLE SENSOR 16mm FOR FLEX



FAFLEXTUBE-05

FLEXIBLE; SET OF 3 EXTENSION TUBES W/ NIPPLE



FAHOLSAC-01

SHOULDER STRAP SDT170, SDT8 & SWITCHBOX



FAHOLSSET8MS

LEATHER CASE FOR SDT8 W/ SHOULDER STRAP




FARPMNLABEL

REFLECTIVE LABEL FOR RPM (PACK OF 4 PCS)



FU.RMB.001--01

REMOTE MONITORING BOX - LEMO






FU.RMB.002--01


REMOTE MONITORING BOX - BNC



Product list - main kits, accessories and spare parts

Part number	Description
FULEAKSPRAY	LEAK SPRAY BOTTLE 200ml DRUCK W/ VAPO
	
FUSEACAC-01	ACCESSORY KIT FOR ACCELOROMETER HANSFORD
	
FUSEACEDS-02--01	EXTENDED DISTANCE SENSOR (EDS) SDT270 with SDT logo
	
FUSEACLUBE-03--A	LUBE ADAPTER FOR USE W/ FUSCRS3-01 (M6 - BSP 1/8")
	
FUSEACLUBENN-03--A	LUBE ADAPTER - NO NAME - FOR USE W/ FUSCRS3NN-01 (M6 - BSP 1/8")
	
FUSEACMAG-01	FLAT MAGNETIC FOOT D25x14 M6
	
FUSEACMAG-02	CURVED MAGNETIC FOOT D30x23
	
FUSEACMP1	MOUNTING PAD - INOX - HEX22 x10mm - (PACK OF 10 PCS)
	
FUTOOLPUNCH	CENTER PUNCH
	
FUTOOLSCRDRIV	SCREW DRIVER FOR BATTERY COVER SDT150, SDT8 & SDT13
	
SA.CP2.MM.F.002--B	NEEDLE ASSEMBLY 133MM CP2 (FOR USE W/ SISENSAMHS130)
	

Product list - main kits, accessories and spare parts

Part number	Description
SAMR270CSH-02	SDT270 - CAP FOR SENSOR HOLDER 02
	
SAMR270PISH-02	SDT270 - PRECISION INDICATOR SENSOR HOLDER 02
	
SAMR270RSH-01	SDT270 - RING SENSOR HOLDER 01
	
SI.CP2.MMF.073-A	ADAPTER M6 Female - M8 Male INOX
	
SI.CP2.MMF.074-A	ADAPTER M6 Female -1/4" UNF Male INOX
	
SIMSENSCP2MP-01--C	MOUNTING PAD CP2
	
SIRUBSENS18MMSI	RUBBER FOR SENSOR Ø18mm
	

Cables

FUCABLCOBNCBNC50-01	CABLE RG58 BNC M<> BNC F, L= 50dm EXT. CABLE TT (BLACK)
	
FUCABLCOBNCBNC50-02	CABLE RG58 BNC M<> BNC F, L= 50dm EXT. CABLE TT (RED)
	
FUCABLCOBNCBNCXX-01	CABLE RG58 BNC M<> BNC F BLACK, L= xx dm (TO SPECIFY)
	

Product list - main kits, accessories and spare parts

Part number	Description
FUCABLCOBNCBNCXX-02	CABLE RG58 BNC M<> BNC M BLACK, L= xx dm (TO SPECIFY)
	
FUCABLCOBNCBNCXX-03	CABLE RG174 BNC M<> BNC M BLACK, L= xx dm (TO SPECIFY)
	
FUCABLCOJ3SBNC25-1	CABLE RG58 JACK 3,5 STEREO ANGLED<>BNC L= 25 dm
	
FUCABLCOLE7BNCXX-1	CABLE RG174 LEMO 7P<>BNC L= xx dm (TO SPECIFY)
	
FUCABLCOLE7BNCXX-3	CABLE FOR FU.RMB.002 - RG58 LEMO 7P<>BNC CHASSIS W/ CABLE GLAND L= xx m (TO SPECIFY)
	
FUCABLCOLE7BWRXX-1	CABLE RG174 LEMO 7P<> BARE WIRES L=xx dm (TO SPECIFY)
	
FUCABLCOLE7LE7XX-1	CABLE RG174 LEMO 7P<> LEMO 7P L= xx dm (TO SPECIFY)
	
FUCABLCOLE7LE7XX-2	CABLE RG174 LEMO 7P<> LEMO 7P 90° L= xx dm (TO SPECIFY)
	
FUCABLMPL17MRJ45-01	NETWORK CABLE LE17F - RJ45 5,0m (SDT270)
	
FUCABLMPL17MRJ45-02	NETWORK/SERIAL CABLE LE17F - RJ45/RS232 2,5m (SDT270)
	
FUCABLMPL17M8FAXX-1	CABLE SPIRAL - LEMO7PM/M8PF ANGLED L= xx dm TO SPECIFY BETWEEN 10..50dm
	

Product list - main kits, accessories and spare parts

Part number	Description
FUCABLMPL7MLE7FXX-2	CABLE FOR FU.RMB.001 - CABLE LE7M<>LE7F W/ CABLE GLAND L= xx dm (TO SPECIFY)
	
FUCABLM8LE7FXX-2	CABLE FOR FU.RMB.001 - CABLE M8 90°<>LE7F W/ CABLE GLAND, L= xxx dm (TO SPECIFY)
	
FUCABLMPTWSUB	CABLE RS232- STEWART<> SUBD9F, L= 1.5 m
	
FUCABLMPSUBUSB	CABLE USB1.1 TO SERIAL DB9M W/SOFT
	
FUCABLP58CAR	CABLE POWER SUPPLY SDT8 W/ CARPLUG
	
FUCABLPWRC7EU-01	POWER CORD 1,5m C7F - EURO
	
FUCABLPWRC7US-01	POWER CORD 1,8m C7F - US
	
FUCABLSPBNCBNC18	CABLE SPIRAL- BNC<> BNC, L= 6/18dm
	
FUCABLSPJ3SBNC18	CABLE SPIRAL- JACK 3,5 STEREO<>BNC, L= 6/18dm
	
FUCABLSPLE7BNC18	CABLE SPIRAL- LEMO 7P<> BNC, L= 6/18dm
	
FUCABLSPLE7BNC18-03	CABLE SPIRAL- LEMO 7P<> BNC, L= 6/18dm (FOR GENERIC ICP ACCELEROMETER)
	

Product list - main kits, accessories and spare parts


Part number	Description
FUCABLSPLE7BNC22	CABLE SPIRAL- LEMO 7P<> BNC, L=10/22dm FOR FUFLEX82* / FUFLEXEX1
	
FUCABLSPLE7LE7-3	CABLE SPIRAL - LEMO7P<> LEMO7P L=6/18dm FOR PYRO2 & RS SENSOR
	
FUCABLSPLE7LE7-4	CABLE SPIRAL - LEMO7PM/LEMO7PF L=6/18dm
	
FUCABLSPLE7LE7-5	CABLE SPIRAL W/ COAX - LEMO7PM/LEMO7PM L=6/18dm (RS SENSOR SDT170)
	
FUCABLSPLE7LE7-6	CABLE SPIRAL - LEMO7P<> LEMO7P L=6/18dm (SINUTEST - SDT270)
	
FUCABLSPLE7LE7-8	CABLE SPIRAL - LEMO7P<> LEMO7P 90° L=6/18dm FOR PYRO2 & RS SENSOR
	
FUCABLSPLE7M8FA-1	CABLE SPIRAL - LEMO7PM/M8PF ANGLED L=6/18dm (HANSFORD ICP ACCELEROMETER)
	
FUCABLSPLE7M8FS-1	CABLE SPIRAL - LEMO7PM/M8PF STRAIGHT L=6/18dm (HANSFORD ICP ACCELEROMETER)
	
SICABUSBAUSBMM	CABLE USB TYPE A - B5 MINI
	

Listening and recording accessories

FUCOAJ6Y Y CONNECTOR FOR HEADPHONE



Product list - main kits, accessories and spare parts




Part number	Description
FUHDPH-1	HEADPHONE SET SDT BLUE NECK
	
FUHDPH-2	HEADPHONE SET SDT BLUE FOLD
	
FUHDPH-3	HEADPHONE SET BLACK NECK
	
FUHDPH-4	LOUDSPEAKER SDT170/200/270
	
FUHDPH-6	HEADPHONE SET BLACK FOLD
	
FUHDPH-7	HEADPHONE SET SDT BLUE NECK - ATEX
	
FUHDPHSET-7	HEADPHONE SET ON HELMET
	
FUHDPHSET-8	HEADPHONE SET ON HELMET W/ INTEGRATED EYE PROTECTION
	
FUHDPHSETA-7	HEADPHONE SET ATEX ON HELMET
	

Batteries

FUBATTAD8	BATTERY CHARGER ADAPTER SDT8
-----------	------------------------------



Product list - main kits, accessories and spare parts

Part number	Description
FUBATTAD8SH	BATTERY CHARGER ADAPTER SDT8 SHERLOG
	
FUBATTR101NICD2	BATTERY PACK SDT101
	
FUBATTR120EX	BATTERY PACK SDT120 Ex-PROOF
	
FUBATTR150DC2	BATTERY PACK SDT150 DC
	
FUBATTR150FW2	BATTERY PACK SDT150 FRIWO
	
FUBATTR170	BATTERY PACK SDT170
	
FUBATTT008	BATTERY SDT8 12V/1.2Ah
	
FUBATTT200	BATTERY PACK 200mW
	
SIBATHOLD-10AA	EMERGENCY BATTERY PACK FOR SDT8 - BATTERY HOLDER FOR 10x AA, WITH COVER AND DC PLUG
	

Battery chargers

FUPWSP150/EU-02	BATTERY CHARGER SDT150 & 200 mW 100-240 EU FRIWO PLUG
-----------------	---



Product list - main kits, accessories and spare parts

Part number	Description
FUPWSP150/UK-02	BATTERY CHARGER SDT150 & 200 mW 100-240 UK FRIWO PLUG
	
FUPWSP150/US-02	BATTERY CHARGER SDT150 & 200 mW 100-240 US FRIWO PLUG
	
FUPWSP150-DC/EU	BATTERY CHARGER SDT150 & 200 mW 240 EU DC PLUG
	
FUPWSP150-J2/EU	BATTERY CHARGER SDT150 & 200 mW 240 EU JACK 2,5mm MONO PLUG
	
FUPWSP170/US	BATTERY CHARGER SDT170 - 110 US
	
FUPWSP8/C8	BATTERY CHARGER SDT8 - 100-240 - W/ POWER CORD 1.5m C7-EURO
	
FUPWSP8/EU	BATTERY CHARGER SDT8 - 100-240 EU
	
FUPWSP8/UK	BATTERY CHARGER SDT8 - 100-240 UK
	
FUPWSP8/US	BATTERY CHARGER SDT8 - 100-240 US
	
FUPWSPUN-01	BATTERY CHARGER UNIVERSAL (SDT170 - 270) W/O CORD (FUCABLPWRC7xx)
	
SIPSSDT8UACC-01	EURO ADAPTOR FOR SDT8 CHARGER
	

Product list - main kits, accessories and spare parts

Part number	Description
SIPSSDT8UACC-02	UK ADAPTOR FOR SDT8 CHARGER
	
SIPSSDT8UACC-03	US ADAPTOR FOR SDT8 CHARGER
	
SIPSSDT8UACC-04	IEC C8 ADAPTOR FOR SDT8 CHARGER
	


Cases

FU.SUIT.BP01	BACK PACK WITH FOAM
	
FUSUIT8	PLASTIC CASE (BLUE) SDT8 W/ FOAM
	
FUSUITFLUS	PLASTIC CASE FLEX.US (BLUE) W/ FOAM
	
FUSUITSYS1	SYSTEMAINER 1 PLASTIC CASE SDT W/O FOAM
	
FUSUITSYS1-2	SYSTEMAINER 1 PLASTIC CASE SDT W/ BOTTOM FOAM & NABA
	
FUSUITSYS1T-1	SYSTEMAINER 1 T-LOC PLASTIC CASE W/ FOAM (ParaDish2)
	
FUSUITSYS3-0	SYSTEMAINER 3 PLASTIC CASE W/O FOAM - W/O LOGO
	

Product list - main kits, accessories and spare parts

Part number	Description
FUSUITSYS3-2	SYSTAINER 3 PLASTIC CASE SDT W/ FOAM SDT170 & FOLIO
	
FUSUITSYS3T-1	SYSTAINER 3 T-LOC PLASTIC CASE W/ FOAM R200/R270, FOLIO
	
FUSUITSYSCART	CART FOR SYSTAINER CASES
	
FUSUITTANK	PLASTIC CASE TANKTEST PROBES (BLUE), W/ INTERNAL FOAM
	

Tank Test sensors

FU.TTSY.TTS2.003	CAMLOCK 2" W/ 2x SENSOR TTS2 Ex TANK TEST - LEMO7PM (RED/ BLACK), L= 50dm - VITON
	
FUTTACSETKA2FSEN	CAMLOCK 2" W/ 2 TT SENSORS (BLACK & RED) - NITRILE
	
FUTTACSETKA2FSEV	CAMLOCK 2" W/ 2 TT SENSORS (BLACK & RED) - VITON
	


Tank Test pipes

FAKA1MG1F	CAMLOCK 1" M - THREAD G1" F
	
FAKA1MG1M	CAMLOCK 1" M - THREAD G1" M
	
FUTTPICONTUB2	TANK CONNECTION TUBE 2" - 50cm KA2" M - G2" F W/ NIPPLE 2" & O-RING 48 x 6
	

Tank test sensors

Tank test pipes

Product list - main kits, accessories and spare parts

Part number	Description
FUTTPIKA1MKA1M	CAMLOCK 1" MALE <-> CAM 1" MALE FOR PIPE CONNECTION
	
FUTTPIKA2MG2F	CAMLOCK 2" M - THREAD G2" F INOX H=62mm
	
FUTTPIPLI5	PLASTIC PIPE 1" TANK TO PUMP L=5m W/O FLAME BUST (2x CAMLOCK 1" FEMALE - INPUT)
	
FUTTPIPL05	PLASTIC PIPE 1" PUMP EXHAUST L= 5m W/ FLAME BUST (2x CAMLOCK 1" FEMALE- OUTPUT)
	
FUTTPIRUB2	2" RUBBER ADAPTER ON 2" MALE GAS THREAD TUBE FOR CONNECTION TUBE
	
FUTTPIRUBI2	RUBBER PIPE 1" TANK TO PUMP Ex-PROOF L=1.5m W/O FLAME BUST (2x CAMLOCK 1" FEMALE - INPUT)
	
FUTTPIRUBI5	RUBBER PIPE 1" TANK TO PUMP Ex-PROOF L=5m W/O FLAME BUSTER (2x CAMLOCK 1" FEMALE - INPUT)
	
FUTTPIRUB05	RUBBER PIPE 1" PUMP EXHAUST Ex-PROOF L=5m W/ FLAME BUSTER (2x CAMLOCK 1" FEMALE- OUTPUT)
	

Other Tank Test accessories

ACPIM417	CALIBRATION OF VACUUM GAGE -1...0 bar
	
FABALTT	BALLONS TANK TEST (100pcs/pack)
	

Product list - main kits, accessories and spare parts

Part number	Description
FAORING48X6	SET O-RING 48x6 NBR (5pcs) FOR TTEST CONNECTION TUBE
	
FAPAC100	TANKTEST RUBBER STOPPER Ø8 - 12mm (13D) (SET 4Pcs)
	
FAPAC101	TANKTEST RUBBER STOPPER Ø14 - 18mm (18D) (SET 4Pcs)
	
FAPAC102	TANKTEST RUBBER STOPPER Ø16 - 21mm (21D) (SET 2Pcs)
	
FAPAC103	TANKTEST RUBBER STOPPER Ø18 - 24mm (24D) (SET 2Pcs)
	
FAPAC104	TANKTEST RUBBER STOPPER Ø20 - 27mm (27D) (SET 2Pcs)
	
FAPAC105	TANKTEST RUBBER STOPPER Ø26 - 31mm (31D) (SET 2Pcs)
	
FAPAC106	TANKTEST RUBBER STOPPER Ø34 - 41mm (41D)
	
FAPAC107	TANKTEST RUBBER STOPPER Ø36 - 44mm (45D)
	
FAPAC108	TANKTEST RUBBER STOPPER Ø46 - 55mm (14)
	
FAPAC109	TANKTEST RUBBER STOPPER Ø50 - 60mm (60D)
	

Product list - main kits, accessories and spare parts

Part number	Description
FAPAC110	TANKTEST RUBBER STOPPER Ø55 - 65mm (65D)
	
FAPAC111	TANKTEST RUBBER STOPPER Ø40 - 49mm (13)
	
FAPAC112	TANKTEST RUBBER STOPPER Ø28 - 34mm (34D)
	
FAPAC113	TANKTEST RUBBER STOPPER Ø73 - 83mm (83D)
	
FAPAC114	TANKTEST RUBBER STOPPER Ø94 - 107mm (107D)
	
FAPAC115	TANKTEST RUBBER STOPPER Ø87 - 100mm (100D) (SET 5PCS)
	
FATTACCABLGNDP	CABLE GRE/YEL L= 5m FOR TTEST EARTH PICKET
	
FUPUMPVACGP45-01	TANK TEST PUMP Ex-PROOF 45m³/h 230V 50Hz MONO(ATEX CERTIFIED)
	
FUPUMPVACSA	TANK TEST PUMP NON Ex-PROOF
	
FUTTACCABALB50N	CABLE RG174- BNC M<> BNC F, W/ PROT. NITR. BLACK, L= 50dm EXTENSION CABLE FOR TT SENSOR
	
FUTTACCABALR50N	CABLE RG174- BNC M<> BNC F, W/ PROT. NITR. RED, L= 50dm EXTENSION CABLE FOR TT SENSOR
	

Product list - main kits, accessories and spare parts

Part number	Description
FUTTACCAR1	CART FOR TANK TEST PUMP (NON Ex-PROOF)
	
FUTTACCOLMAT	KOLMAT PASTE 700ml
	
FUTTACGNDP1	EARTH PICKET W/ CABLE GRE/YEL L= 50dm
	
FUTTACLEVGA	TTEST LEVEL GAGE (SET OF 3 THREADED TUBES & SLEEVE)
	
FUTTACOILCL	SDT OIL CLEANER (5l) TANK TEST READY TO USE
	
FUTTACSETRUBS	TANKTEST - RUBBER STOPPER SET
	
FUTTACWATERFIND70	WATER INDICATOR PASTE (70gr)
	
FUTTSB170V4	SWITCH BOX TANK TEST SDT170 V.4 W/ CABLE & LEMO 7P
	
SIOILGEVGP45AT-01	OIL FOR VACUUM ATEX COMPRESSOR GEV GP45 ATEX - 1L
	
SIOILVG100COMP	OIL FOR VACUUM ATEX COMPRESSOR - 1L
	
SIPIM400	PRESSURE GAGE 0...1 bar, INOX HOUSE Ø63mm, BACK CENTER G¾", CLASS 1,6
	

Product list - main kits, accessories and spare parts

Part number	Description
SIPI401	RD23 VACUUM -1...0 bar, BOURDON - INOX HOUSE Ø63mm, BACK CENTER G¼", CLASS 1,6
	
SIPI411	VACUUM GAGE -1...0 bar W/ GLYCERINE - RADIAL BOTTOM G¼" FOR EX-PROOF PUMP
	
SIPI417	VACUUM GAGE -1...0 bar W/ GLYCERINE - BOTTOM G¼"
	
SIPI417CERT	CALIBRATION CERTIFICAT FOR VACUUM GAGE-1...0 bar W/ GLYCERINE
	
SIPI418	VACUUM GAGE -400...0 mbar W/ GLYCERINE - BOTTOM G¼"
	
SIPI418CERT	CALIBRATION CERTIFICAT FOR VACUUM GAGE-400...0 mbar W/ GLYCERINE
	

Spare receivers

Spare receivers

FUFLUS-01	FLEX.US RECEIVER
	
FUR200ASD	SDT200 RECEIVER ATEX W/ MANUAL, RUBBER CURB RING & W/O BATTERY
	
FUR200SD	SDT200 RECEIVER W/ MANUAL, RUBBER CURB RING & W/O BATTERY
	
FUR270ASB	SDT270 RECEIVER ATEX W/ BLUE ATEX RUBBER PROTECTION & W/O BATTERY
	

Product list - main kits, accessories and spare parts

Part number	Description
FUR270SB	SDT270 RECEIVER W/ BLUE RUBBER PROTECTION & W/O BATTERY



Spare transmitters

FUT008MS	SDT8 TRANSMITTER, BLUE W/ BATTERY
FUT008MSG	SDT8 TRANSMITTER, SHERLOG RED W/ BATTERY
FUT200B	200 mW BI-SONIC TRANSMITTER
FUT200D	200 mW DIRECTIONAL TRANSMITTER



Demonstration equipment

FADEMOTTDR01	TT DEMO DRUM Ø200 x660
FADEMOTTPIPE01	TT DEMO CONNECTION PIPE & ACCESSORIES
FUEMOBB	DEMO BENCH BEARINGS W/ CASE
FUEMOBL-03	DEMO BENCH LEAKS V3 W/ SYSTAINER 3 CASE
FUEMOBL4V	DEMO BENCH LEAKS MODULE 4 VALVES




Spare transmitters

Demonstration equipment

Product list - main kits, accessories and spare parts

Part number	Description
FUEMOSP	DEMO SPARK GENERATOR W/ BATTERY CHARGER
	
FUEMOTTPUMP01	VACUUM PUMP TT DEMO SYSTEM
	
FUEMOTTSET-01	TT DEMO SYSTEM W/ DRUM Ø250 x 660, VACUUM PUMP & CON. PIPE
	
FUSUITSYS4-3	SYSTEM 4 PLASTIC CASE SdT W/ FOAM FOR DEMO BEARING
	

Spare parts SdT 170/Sherlog

FAHOLS170-01	SDT170 RUBBER HOLSTER BLUE
	
FAHOLS170-02	SDT170 RUBBER HOLSTER RED (Sherlog)
	
FAR170ACC	SDT170 LEMO 7 ASSEMBLY
	
FAR170BATCONT	SDT170 BATTERY CONTACT BOARD
	
FAR170COM	SDT170 STEWART ASSEMBLY
	
FAR170FP-01	SDT170 FRONT W/ KEYBOARD & PC REVERSED FLATFLEX (OLD MODEL)
	

Product list - main kits, accessories and spare parts

Part number	Description
FAR170FP-02	SDT170 FRONT W/ KEYBOARD & PC
FAR170FP-03	SDT170 SHERLOG FRONT W/ KEYBOARD & PC
FAR170FP-04	SDT170 SHERLOG FRONT W/ KEYBOARD & PC REVERSED FLATFLEX (OLD MODEL)
FAR170JK6	SDT170 JACK 6.3mm ASSEMBLY
FAR170LCD	SDT170 LCD W/ZEBRA
FAR170MB-04	SDT170 MAIN BOARD I4 - CALIBRATED
FAR170MB-04/SE	Std Exch. SDT170 MAIN BOARD Is. 04 W/ LCD - CALIBRATED
FAR170PROF	SDT170 CASE W/ BATTERY CASE (W/O SIDE PLATES NOR FRONT)
FAR170SCREWS	SCREW SET SDT170 CASING (6 pcs)
FAR170SENS-02	SDT170/270 SENSOR ASSEMBLY
FAR170SP01	SDT170 SENSOR SIDE PLATE ASSEMBLY

Product list - main kits, accessories and spare parts

Part number	Description
FAR170SP02	SDT170 CONNECTOR SIDE PLATE ASSEMBLY
	
FAR270SCREWSET	SDT270 - SCREW SET FOR CASING (8 pcs)
	
SILEDBACKL/170	SDT170 BACKLIGHT
	
SIRUB170STW	SDT170 RUBBER STEWART
	

Leak tags

Leak tags

FULEAKTAGSET1	LEAK TAG SET ENGLISH (1000 pcs, numbered) W/ TIE
	
FULEAKTAGSET2	LEAK TAG SET FR (1000 pcs, numbered) W/ TIE
	
FULEAKTAGSET3	LEAK TAG SET NL (1000 pcs) W/ TIE
	

SDT270
upgrade keys

SDT270 upgrade keys

FAUPGRKEY200T	SDT200 ACTIVATION KEY - BUILT-IN TEMPERATURE SENSOR
FAUPGRKEY270A	SDT270 ACTIVATION KEY - ICP POWER SUPPLY (ACCELEROMETRY)
FAUPGRKEY270DD	SDT270 DD UPGRADE KEY - DYNAMIC DOWNLOAD WITH DATADUMP
FAUPGRKEY270DD-DU	SDT270 DD TO DU UPGRADE KEY - DYNAMIC DOWNLOAD WITH UAS
FAUPGRKEY270DD-DW	SDT270 DD TO DW UPGRADE KEY - DYNAMIC & WEBSERVICE KEY
FAUPGRKEY270DU	SDT270 DU UPGRADE KEY - DYNAMIC DOWNLOAD & UPLOAD FROM UAS
FAUPGRKEY270DU-DW	SDT270 DU TO DW UPGRADE KEY - DYNAMIC & WEBSERVICE KEY
FAUPGRKEY270DW	SDT270 DW UPGRADE KEY - DYNAMIC & WEBSERVICE KEY
FAUPGRKEY270E	SDT270 E UPGRADE KEY - EXPERT
FAUPGRKEY270G	SDT270 ACTIVATION KEY - TRIGGER FUNCTION
FAUPGRKEY270R	SDT270 ACTIVATION KEY - BUILT-IN RPM SENSOR
FAUPGRKEY270SD	SDT270 SD UPGRADE KEY - STATIC DOWNLOAD
FAUPGRKEY270SD-DD	SDT270 SD TO DD UPGRADE KEY - DYNAMIC DOWNLOAD WITH DATADUMP
FAUPGRKEY270SD-DU	SDT270 SD TO DU UPGRADE KEY - DYNAMIC DOWNLOAD WITH UAS
FAUPGRKEY270SD-DW	SDT270 SD TO DW UPGRADE KEY - DYNAMIC & WEBSERVICE KEY

Product list - main kits, accessories and spare parts

Part number	Description
FAUPGRKEY270SD-SU	SDT270 SD TO SU UPGRADE KEY - STATIC DOWNLOAD WITH UAS
FAUPGRKEY270SH	SDT270 SH UPGRADE KEY - SHERLOG + DOWNLOAD WITH SHERLOG REPORTER
FAUPGRKEY270SS	SDT270 SS UPGRADE KEY - STATIC STORAGE
FAUPGRKEY270SS-DD	SDT270 SS TO DD UPGRADE KEY - DYNAMIC DOWNLOAD WITH DATADUMP
FAUPGRKEY270SS-DU	SDT270 SS TO DU UPGRADE KEY - DYNAMIC DOWNLOAD WITH UAS
FAUPGRKEY270SS-DW	SDT270 SS TO DW UPGRADE KEY - DYNAMIC & WEBSERVICE KEY
FAUPGRKEY270SS-SD	SDT270 SS TO SD UPGRADE KEY - STATIC DOWNLOAD WITH DATADUMP
FAUPGRKEY270SS-SU	SDT270 SS TO SU UPGRADE KEY - STATIC DOWNLOAD WITH UAS
FAUPGRKEY270SU	SDT270 SU UPGRADE KEY - STATIC DOWNLOAD & UPLOAD FROM UAS
FAUPGRKEY270SU-DD	SDT270 SU TO DD UPGRADE KEY - DYNAMIC DOWNLOAD WITH DATADUMP
FAUPGRKEY270SU-DU	SDT270 SU TO DU UPGRADE KEY - DYNAMIC DOWNLOAD WITH UAS
FAUPGRKEY270SU-DW	SDT270 SU TO DW UPGRADE KEY - DYNAMIC & WEBSERVICE KEY
FAUPGRKEY270T	SDT270 ACTIVATION KEY - BUILT-IN TEMPERATURE SENSOR
FAUPGRKEY270TT	SDT270 TT UPGRADE KEY - TANKTEST KEY & TANKTEST REPORTER LICENSE

Software

FASFTWKMUSUASD01	UAS Dynamic - 1 License
FASFTWUASD01	LICENSE UAS STATIC & DYNAMIC SOFTWARE
FASFTWUASD05	PACK 5 LICENSES UAS STATIC & DYNAMIC SOFTWARE
FASFTWUASD10	PACK 10 LICENSES UAS STATIC & DYNAMIC SOFTWARE
FASFTWUASDN01	LICENSE UAS DYNAMIC + NETWORK SOFTWARE
FASFTWUASDN05	PACK 5 LICENSES UAS DYNAMIC + NETWORK SOFTWARE
FASFTWUASDN10	PACK 10 LICENSES UAS DYNAMIC + NETWORK SOFTWARE
FASFTWUASS01	LICENSE UAS STATIC SOFTWARE
FASFTWUASS05	PACK 5 LICENSES UAS STATIC SOFTWARE
FASFTWUASS10	PACK 10 LICENSES UAS STATIC SOFTWARE
FASFTWUASSN01	LICENSE UAS STATIC + NETWORK SOFTWARE
FASFTWUASSN05	PACK 5 LICENSES UAS STATIC + NETWORK
FASFTWUASSN10	PACK 10 LICENSES UAS STATIC + NETWORK
FASFTWUASUPD2DN01	LICENSE UPGRADE FROM UAS DYNAMIC TO UAS DYNAMIC NETWORK
FASFTWUASUPS2D01	LICENSE UPGRADE FROM UAS STATIC TO DYNAMIC - NO NETWORK
FASFTWUASUPS2D05	PACK 5 LICENSES UPGRADE FROM UAS STATIC TO DYNAMIC - NO NETWORK
FASFTWUASUPS2D10	PACK 10 LICENSES UPGRADE FROM UAS STATIC TO DYNAMIC - NO NETWORK
FASFTWUASUPS2DN01	LICENSE UPGRADE FROM UAS STATIC TO UAS DYNAMIC NETWORK
FASFTWUASUPS2SN01	LICENSE UPGRADE FROM UAS STATIC TO UAS STATIC NETWORK
FASFTWUASUPSN2DN01	LICENSE UPGRADE FROM UAS STATIC NETWORK TO UAS DYNAMIC NETWORK

Calibration and functional tests

ACMFHP	CALIBRATION MFL HP
ACR150	CALIBRATION SDT150
ACR150R	CALIBRATION SDT150 W/ REPORT
ACR170	CALIBRATION SDT170 - OBSOLETE PART
ACR170R	CALIBRATION SDT170 W/ REPORT
ACR270	CALIBRATION SDT200/270 W/ REPORT
ACSEDBA2	CALIBRATION DBA SENSOR
ACSOND170	CALIBRATION CONTACT PROBE 170
ACSOND270-01	CALIBRATION CONTACT PROBE RS1 & THREADED SENSOR 270
ACT200	CALIBRATION 200 mW BI-SONIC
ACT200R	CALIBRATION 200 mW BI-SONIC W/ REPORT
ACTTSB170	CALIBRATION SWITCHBOX SDT170MTT
AT.RAE1.001	FUNCTIONAL TEST REFERENCE EMITTER RAE1
ATBATTR150	FUNCTIONAL TEST BATTERY SDT150
ATBATTR170	FUNCTIONAL TEST BATTERY SDT170

Product list - main kits, accessories and spare parts

Part number	Description
ATBATTR270	FUNCTIONAL TEST BATTERY SDT270
ATBATT008	FUNCTIONAL TEST BATTERY SDT8
ATCABLSP	FUNCTIONAL TEST CABLE SPIRAL
ATFLEX-01	FLEX FUNCTIONAL TEST
ATFLUS	FLEX-US FUNCTIONAL TEST
ATHDPH	FUNCTIONAL TEST HEADPHONE SET or LOUD SPEAKER
ATINTTEMP	T° INTERFACE FONCTIONAL TEST
ATMAGN	TEST MAGNETIC SENSOR
ATMFLP	MFL LP FONCTIONAL TEST
ATPARA	FUNCTIONAL TEST PARABOLIC
ATPUMPEX	TEST VACUUM PUMP ENIVAC EXP
ATPUMPNOEX	TEST VACUUM PUMP NON-EXP
ATPWSPSTD	FUNCTIONAL TEST BATTERY LOADER STANDARD
ATR150	FUNCTIONAL TEST RECEIVER SDT150
ATR170	FUNCTIONAL TEST SDT170
ATR170KIT-01	FUNCTIONAL TEST KIT SDT170 W/ CALIBRATION SDT170
ATR270	FUNCTIONAL TEST SDT270
ATRPMN	FUNCTIONAL TEST RPM SENSOR
ATSEDBA2	TEST DBA SENSOR
ATSHERKIT-01	FUNCTIONAL TEST KIT SHERLOG S+ W/ CALIBRATION SHERLOG
ATSHERKIT-02	FUNCTIONAL TEST KIT SHERLOG TA W/ CALIBRATION SHERLOG
ATT008-2	FUNCTIONAL TEST SDT8 S/MS
ATTTKIT-01	FUNCTIONAL TEST KIT TT W/ CALIBRATION SDT150 & REPORT
ATTTKIT-02	FUNCTIONAL TEST KIT TT W/ CALIBRATION SDT170MTT & REPORT
ATTTPL	FUNCTIONAL TEST PLOTTER FOR TTEST 150
ATTTPU	FUNCTIONAL TEST PUMP TT
ATTSB150	FUNCTIONAL TEST SWITCH BOX 150
ATTSB170	FUNCTIONAL TEST SWITCH BOX SDT170MTT
ATTTSE	FUNCTIONAL TEST SENSOR TT

Appendix

Remarks concerning battery loaders and power cables :

SDT270, SDT200 and SDT 170 detectors

SDT270, SDT200 and SDT 170 kits include a universal battery charger for the detector and a European type power cable (with C plug type). This charger can be used with 100-240 voltages (50-60Hz).



Other power cables are available upon request:

- US plug (A type) part nr. FUCABLPWRC7US-01



- UK plug (G type) part nr. FUCABLPWRC7UK-01



These power cables are standard and thus also available in most hardware stores.

SDT8 transmitter

Kits containing an SDT8 transmitter include a battery charger equipped with an interchangeable European mains power plug (C type). This charger can be used with 100-240 voltages (50-60Hz).



Other mains power plugs are available upon request:

- US plug (A type) part nr. SIPSSDT8UACC-03



- UK plug (G type) part nr. SIPSSDT8UACC-02



- C8 plug (for C7 mains power cord) part nr. SIPSSDT8UACC-04



There are also mains power plug adaptors available in most hardware stores.

SDT 200mW transmitter

Kits containing an SDT 200 mW transmitter include a charger with European mains power plug (C type). This charger can be used with 100-240 voltages (50-60Hz).

Chargers with other mains power plug types are available upon request:

- US plug (A type) part nr. FUPWSP150/US-02
- UK plug (G type) part nr. FUPWSP150/UK-02

There are also mains power plug adaptors available in most hardware stores.

SDT150 detector

The battery loader for the SDT150 is the same as for the SDT200mW transmitter.

SDT sensors & accessories: compatibility and required cables

	SDT270	SDT200	SDT 170	SDT 150
Ultrasonic sensors				
Flexible sensors (FUFLEX306, FUFLEX555, FUFLEX556, FUFLEX556A,)	FUCABLSPLE7BNC18 or FUCABLSPLE7BNC22			FUCABLSPJ3SBNC18
Flexible sensors (FUFLEX825, FUFLEX826)	FUCABLSPLE7BNC22			FUCABLSPJ3SBNCXX
ATEX flexible sensors (FUFLEXEX1, FUFLEXEX2)	FUCABLSPLE7BNC22		not applicable	not applicable
Flexible sensors for SDT Sherlog (FUFLEX825SH, FUFLEX826SH)	compatible (no additional cable required)			not compatible
Contact probe SDT 170 (FUSONDSET170*, FUSOND170*, FUSONDSET170-03*, FUSOND170MG*)	not compatible		compatible (no additional cable required)	not compatible
RS1NLxxx needle contact probe (FUSOND270-xx)	FUCABLSPLE7LE7-3		FUCABLSPLE7LE7-5	not compatible
Sensor threaded M4 (FUSCRS2/BNC*, FUSCRSSET2/...*)	FUCABLSPLE7BNC18			FUCABLSPJ3SBNC18
Threaded sensor RS1 (FUSCRS3-01)	FUCABLSPLE7LE7-3		FUCABLSPLE7LE7-5	not compatible
Magnetic sensor (FUMAGN/BNC*)	FUCABLSPLE7BNC18			FUCABLSPJ3SBNC18
Parabolic sensor (FSPARA25*)	compatible (no additional cable required) remark: requires EMC coil		compatible (no additional cable required)	not compatible
ParaDish2 parabolic sensor (FS.PAR2.001)	compatible (no additional cable required)		not compatible	not compatible
Reflector (FUSEUSCOLL01)	FUCABLSPLE7BNC18			FUCABLSPJ3SBNC18


Non-ultrasonic sensors				
Sensor MFL low pressure (FUMFLP1K)	compatible (no additional cable required)		compatible (no additional cable required)	not compatible
ICP accelerometer (SISENSAMHS130)	FUCABLSPLE7M8FA-1 or FUCABLSPLE7M8FS-1 (SDT270 requires specific PCB version and firmware)	not compatible	not compatible	not compatible
Pyrometer (FUPYRO2)	not compatible		FUCABLSPLE7LE7-3	not compatible
Tachometer (FURPMN)	not compatible		FUCABLSPLE7LE5/18	not compatible
Sensor dBA SDT170 (FUSEDBA2*)	not compatible		compatible (no additional cable required)	not compatible

Accessories				
Interface thermo-couple SDT170 (FUINTTEMP170)	not compatible		compatible	not compatible
Interface for US sensor (FUINTUS-01)	not compatible		compatible	not compatible
EDS SDT 170/150 (FUSEACEDS-01*)	requires sensor adapter (SAMR270SAD-01)		compatible	compatible
EDS2 (FUSEACEDS-02--01)	compatible		not compatible	not compatible
Lube adapter for SDT 170 contact probe or sensor threaded M4 (FUSEACLUBE-02)	requires sensor threaded M4 (FUSCRS2/BNC*) + cable		requires SDT 170 contact probe (FUSOND170*) or sensor threaded M4 (FUSCRS2/BNC*) + cable	requires sensor threaded M4 (FUSCRS2/BNC*) + cable
New lube adapter for RS1T threaded sensor (FUSEACLUBE-03)	requires RS1T threaded sensor (FUSCRS3-01) + cable			not compatible

* Production of these articles has been stopped. Available while stocks last. Contact SDT for more information.

SDT Contact Sensors Overview

DC.CP2.FO.01--j



Quick guidelines concerning the use of accelerometers with SDT270 detectors

Accelerometers cannot be used with SDT270 ATEX detectors.

The SDT270 needs a PCB Issue 6 or higher and firmware version should be 9.92 or higher.

The ICP Power Supply should be activated on the detector (using firmware upgrade key FAUPGRKEY270A).

The 100mV/g ICP accelerometer proposed by SDT has an M8 connector (4 pin). It should be connected to the SDT270 with one of these cables: FUCABLSPLE7M8FA-1 or FUCABLSPLE7M8FS-1 (see illustration below). For connecting other standard 100mV/g ICP accelerometers, SDT provides a cable with BNC connector: FUCABLSPLE7BNC18-13 (see illustration below). Important note: this cable (with Lemo7 and BNC connectors) is specific for use with accelerometers. SDT provides other cables with same connectors (meant for connecting other sensor types), but these are not compatible with accelerometers. The proper Lemo7-BNC cable type for accelerometers is distinguishable by the yellow sleeve on the lemo connector.

SDT proposes a contact needle (partnumber SA.CP2.MMF.002-B) with male M6 thread which can be screwed on the accelerometer. The accelerometer is delivered together with a headless screw which is required for mounting other SDT accessories on the accelerometer: mounting pads (partnumber FUSEACMP1), flat magnetic foot (partnumber FUSEACMAG-01) and curved magnetic foot (partnumber FUSEACMAG-02).

