



When replacing the sensors observe all of the safety precautions, information and warnings in the manual of the web guiding controller used.

Old Sensors

IR 2001



Replace connecting cable!

IR 2002



Replace connecting cable!

IR 2005



Replace connecting cable!





New Sensor

IR 2011





Connecting cable
BST part number:
128 967 (length 10 m)
133 457 (length 5 m)
133 456 (length 3 m)

Replacement with ekr 1500



Replacement with ekr 500 Plus





When replacing the sensors observe all of the safety precautions, information and warnings in the manual of the web guiding controller used.

Old Sensors

IR 2001



Replace connecting cable!

IR 2002



Replace connecting cable!

IR 2005



Replace connecting cable!





New Sensor

IR 2011



Connecting cable
BST part number:
128 967 (length 10 m)
133 457 (length 5 m)
133 456 (length 3 m)

Replacement with ekrPro Com⁵⁰



Replacement with ekrPro Com⁶⁰

